

Safety Notes

Please Read Before Use

This manual should be read and understood before attempting to install, operate, maintain or overhaul a PLC. The user should be completely familiar with all associated documentation, safety practices, guidelines and necessary device knowledge before move on accordingly.

Two symbols are used to highlight the safety notes mentioned in this manual: DANGER and CAUTION. They are listed below with brief descriptions.




DANGER

Indicates that misoperation could cause severe consequence like death or major injury.



CAUTION

Indicates that misoperation could cause physical or property damage.


In addition, the  CAUTION warnings also indicate that severe consequences are possible under certain conditions. Please make sure all operations are carried out in accordance with these guidelines to avoid such consequences.

Please keep this manual properly for reference whenever necessary and distribute it to the end users.

Safety Notes

Please Read Before Use


1. Design Guidelines

|  DANGER | Page Ref. |
|--|--------------|
| <ul style="list-style-type: none">• Please set up an external safety circuit for the PLC, so that if the external power fails or the PLC breaks down, the system can still operate with safety.• Any misoperation or mis-output could possibly cause accident.• External protective circuits should be designed for a PLC to avoid mechanical damage. E.g. Emergency Stop, Forward/Reverse Inter-Lock or Upper/Lower Limit Positioning.• A PLC CPU detects abnormal states through self-examine functions such as Watch Dog Timer (WDT) and will then switch off all its outputs. Anyway, it is not able to detect the state of the input/output control circuits and thus may not be able to control the output when error occurs. So in order to protect the mechanical equipment, some external safety circuits and agencies should be designed.• A PLC may not be able to control the ON/OFF state when error occurs to its output relay and transistor, etc. So for crucial output signals which could cause major accident, some external safety circuit and agencies should be designed, to make sure the mechanical devices operate with safety. | 12 41 |

Safety Notes

Please Read Before Use







2. Installation Guidelines

|  CAUTION | Page Ref. |
|---|-----------|
| <ul style="list-style-type: none">• The product should be used under certain conditions as stated in “1-6 General Specifications” of this manual.• The product should NOT be used under the following conditions:<ol style="list-style-type: none">(1) Excessive or conductive dust, corrosive or flam. gas, or oily smoke.(2) Excessive heat, moisture or rain, condensation, regular impact shocks or excessive vibration. The above-mentioned conditions may cause electric shock, fire or misoperation and damage the product.• Take special care not to allow debris to fall inside the unit during installation e.g. making screw holes, cut wires etc, for it may cause fire, product damage or mis-reaction.• Once the installation is complete, remove the protective paper band on the PLC to prevent fire, product damage or mis-reaction caused by the overheating.• Install the connection cables and expansion modules properly, and make sure they are fixed, for loose contact may cause mis-reaction.• DO NOT install the product on the basement, top or along the vertical direction of a switchboard, to avoid overheating.• Ensure that there is a space larger than 50 mm around the installed PLC and it is kept as far as possible from high-voltage cables, high-voltage equipment and power equipment. | 29 |

Safety Notes

Please Read Before Use



3. Wiring Guidelines

|  DANGER | Page Ref. |
|--|----------------|
| <ul style="list-style-type: none">• Cut all the external power during installation or wiring, to avoid electric shock or product damage.• Close the terminal cover before switch on the power supply after installation or wiring, to avoid electric shock. | 31 |
|  CAUTION | Page Ref. |
| <ul style="list-style-type: none">• When wiring AC supplies, it must be connected to the correct input terminal, for if it is connected to DC (Direct Current) input/output terminal or DC power terminal, the PLC will be damaged.• DO NOT connect the 24V OUT  terminal of a PLC main unit to the 24V OUT  terminal of an extension unit, or to the  terminal of an external power supply, for it may damage the PLC.• DO NOT do any external wiring for the empty terminals  of a PLC, for it may damage the product.• Connect the grounding terminal of the main unit using the class 3 grounding standard, but DO NOT ground it with major power systems. (Refer to 1-6) | 31 35 41 |

Safety Notes

Please Read Before Use

4. Operation and Maintenance Guidelines

|  DANGER | Page Ref. |
|--|-----------|
| <ul style="list-style-type: none">• DO NOT contact the terminal when the power supply switched on, to avoid electric shock or product mis-reaction.• Switch off the power supply before clean or tighten the terminal, to avoid electric shock.• Carry program-change-in-operation (force output, RUN, STOP, etc) ONLY after carefully read and understand this manual and safety is ensured, for misoperation may cause equipment damage or accident. | 53 |
|  CAUTION | Page Ref. |
| <ul style="list-style-type: none">• Switch off the power supply before assemble or overhaul the selected optional units, to avoid damage to the expansion or main units.• Switch off the power supply before assemble or overhaul the connection cable, to avoid damage or misoperation.• DO NOT assemble or overhaul the product cage, or alter it by yourself, for it may cause product damage, mis-reaction or fire.• Contact the nearest distributor or Vigor Electric Corp directly for any product repairing matters. | 53 |

Safety Notes

Please Read Before Use

5. Recycling Guidelines

|  CAUTION | Page Ref. |
|--|-----------|
| <ul style="list-style-type: none">• Dispose the product as industrial waste when it is to be discarded as worthless. | 58 |


| | | | |
|--|----|--|----|
| Foreword | 2 | 4. Input Specifications and External Wiring | 35 |
| 1. VH Series PLC Introductions | 3 | 4-1 Input Point Specifications | 36 |
| 1-1 System Configuration | 4 | 4-2 Input Point Wiring Introduction | 37 |
| 1-2 Component Names | 5 | 4-3 Input Wiring Notes | 38 |
| 1-3 Model Numbering | 8 | 4-4 About the X0–X7 Input Points | 39 |
| 1-4 Extension Units Introductions | 10 | 5. Output Specifications and External Wiring | 40 |
| 1-5 Error Code Display Function Introductions | 11 | 5-1 Output Point Specifications | 41 |
| 1-6 General Specifications | 12 | 5-2 Output Wiring Introduction | 42 |
| 1-7 Performance Specification | 14 | 5-3 Output Wiring Notes | 43 |
| 1-8 Instruction Tables | 16 | 5-4 About the Y0 Output Point | 44 |
| 1-9 Special Components and Error Messages | 19 | 6. Optional Modules | 45 |
| 1-10 Terminal Layouts | 23 | 6-1 Models of Optional Modules | 45 |
| 1-11 Product List | 26 | 6-2 Communication Expansion Board | 46 |
| 1-12 Dimensions | 28 | 6-3 Memory Card Slot Expansion Card | 48 |
| 2. Installation Work | 29 | 6-4 Use the VB-MP1R | 49 |
| 2-1 Installation Guides | 30 | 6-5 Connection Cables | 51 |
| 2-2 Wiring Guidelines | 30 | 7. Operation Rehearsal, Maintenance and Error Checking .. | 53 |
| 3. Power Specifications and External Wiring | 31 | 7-1 Operation Rehearsal | 54 |
| 3-1 Power Specifications | 32 | 7-2 Determine Exceptional Behavior through the LED Indicator .. | 55 |
| 3-2 AC Power Wiring Example | 33 | 7-3 Maintenance | 58 |
| 3-3 DC Power Wiring Example | 34 | | |

About the Manual


When purchasing VH series PLC main unit, a copy of this hardware manual will be attached. For programming tutorial or instruction tables, please refer to the "Programming Manual for M, VB and VH Series PLC".

| Manual Name | Content |
|---|---|
| Hardware Manual for VH Series PLC (This manual) | <ul style="list-style-type: none">• Introduction to the VH series PLC• Specification and guidelines for the operation environment, wiring and installation of the VH series PLC• Specification and instructions for the installation and operation of the selected optional units.• Instructions for the operation, maintenance and fault repair of the PLC. |
| Programming Manual for M, VB and VH Series PLC | <ul style="list-style-type: none">• Introduction to the various components of the M, VB and VH series PLC.• Introduction to the basic and applied instructions.• Programming guidelines. |

About the Trademark

- The  trademark belongs to the VIGOR ELECTRIC CORP. of Taiwan.
- WINDOWS is a registered trademark under Microsoft Corporation of United States.
- Any other product or service names mentioned in this manual are all intelligent property of their respective owners.

Great, Reliable Performance at a Budget Price



◇ Error Code Display Function

- The machine maintenance work is made easier by this practical powerful function.

◇ Complete Product Model Collections, Cost-Saving Customized Module Assembling

- 8 models of main unit to be chosen from: 10/14/20/24/28/32/40/60 points.
- Many I/O extension module models to provide complete extension ability: 4X/4Y~16X/16Y, etc.

◇ Complete and Powerful Communication Ability

- Built-in RS-232 interface can connect with PC or HMI (Human Machine Interface).
- Can extend to a local area monitor network.


◇ Small & Compact Design to Save Install Space

◇ Complete and Powerful System Functions

- No-battery program storage device: Flash ROM.
- Download program with component and program comments to make the maintenance work easier.
- Complete collection of instructions, including compare point instruction, makes the PLC programming work easier.
- Password Lock function on the PLC program, fully protect the intelligent property.
- The RTC (Real Time Clock) expansion card can set timer and run periodical automated control.
- Wide range voltage design (AC85V~264V) of the power input.

1. VH Series PLC Introductions


1-1 System Configuration



1. VH Series PLC Introductions

1-2 Component Names

VH-10/14MR




DO NOT connect any PC USB interface to the programming tool communication port for the comm. Interface is RS-232 although it is an USB A-type connector.



CAUTION

Use the MWPC-200 cable to connect the programming tool communication port to PC RS-232 interface. Use VBUSB-200 cable instead if the PC has no RS-232 interface. The VH-10/14 MR main unit has no comm. expansion/memory card/IO extension slots.

1. VH Series PLC Introductions




CAUTION

DO NOT connect any PC USB interface to the programming tool communication port for the comm. Interface is RS-232 although it is an USB A-type connector. Use the MWPC-200 cable to connect the programming tool communication port to PC RS-232 interface. Use VBUSB-200 cable instead if the PC has no RS-232 interface.

- Status Indicator LED

| LED | Action | Status |
|----------------|------------|-------------------------------|
| PWR (GREEN) | ON | Power in Supply |
| | OFF | Power Cut |
| RUN (GREEN) | ON | RUN |
| | OFF | STOP |
| ERR (RED) | ON | System Error (Stop Running) |
| | FLICKERING | Abnormal State (Stop Running) |
| | OFF | Normal State |

- Sliding Switch




| Switch Number | Function | OFF | ON |
|---------------|--------------------------|------------------|--------------------|
| 1 | RUN/STOP Switch | STOP | RUN |
| 2 | I/O Display Range Switch | X0~X37 Y0~Y37 | X40~X77 Y40~Y77 |

- The Programming Tool Auxiliary Port is used to connect to HMI or SCADA (Supervisor Control and Data Acquisition) System. This auxiliary port is parallel linked with the Programming Tool Communication Port, so they cannot be used at the same time.


1. VH Series PLC Introductions

1-3 Model Numbering


- Model Numbering Tag (Pasted on the right side of a PLC)




- Main Unit Model Numbering



- Extension Unit Model Numbering




- Extension Module Model Numbering



1. VH Series PLC Introductions

1-4 Extension Units Introductions





- VH-10MR and VH-14MR do not have the I/O Extension function
- VH Series Main Unit always occupies the I/O address X0~X17/Y0~Y17, and thus the first Expansion Unit /Module will use the I/O address from X20/Y20 onwards.
- VH-8XY Extension Module occupies 8 input points and 8 output points.
- VH-28XYR Extension Module occupies 24 input points and 8 output points.
- Maximum output/input points: 128 points X0~X77 /Y0~Y77
- VH-40MR consists of a VH-32MR Main Unit and a VH-8X Module, occupies I/O addresses X0~X27/Y0~Y17.
- VH-60MR consists of a VH-32MR Main Unit and a VH-28XYR Module, occupies I/O addresses X0~X47/Y0~Y27.
- VH series Main Unit and Extension Unit have self-supply power units, but the Extension Module does not. So the Extension Module needs to get power from a Main Unit or Expansion Unit.
- 2 Conditions must be met when the Main Unit or Extension Unit connect to other modules:
 - (1) The number of modules connected after the Main Unit or Extension Unit should be ≤ 6 .
 - (2) The total number of ON relays in the Main Unit or Extension Unit and the Extension Modules connected after them should be ≤ 32 .

1-5 Error Code Display Function Introductions

The Multi-Functional Display on the Main Unit panel has an Error Code Display function besides the I/O Display function. It can display 109 error codes from 01~99 and E0~E9. This function is very practical and it makes the device maintenance work much easier than before.

The D9080 special register controlled Multi-Functional Display of VH Series PLC has the following functions:

| Value of D9080 | MFD Function |
|----------------|-------------------------------------|
| 0 | Displays Input/Output status of PLC |
| 1~99 | Displays 01~99 numbers |
| 100~109 | Displays E0~E9 Error Code |



1. VH Series PLC Introductions

1-6 General Specifications

Design Guidelines




DANGER

- Please set up an external safety circuit for the PLC, so that if the external power fails or the PLC breaks down, the system can still operate with safety.
- Any misoperation or mis-output could possibly cause accident.
- External protective circuits should be designed for a PLC to avoid mechanical damage. E.g. Emergency Stop, Forward/Reverse Inter-Lock or Upper/Lower Limit Positioning.
- A PLC CPU detects abnormal states through self-examine functions such as Watch Dog Timer (WDT) and will then switch off all its outputs. Anyway, it is not able to detect the state of the input/output control circuits and thus may not be able to control the output when error occurs. So in order to protect the mechanical equipment, some external safety circuits and agencies should be designed.
- A PLC may not be able to control the ON/OFF state when error occurs to its output relay and transistor, etc. So for crucial output signals which could cause major accident, some external safety circuit and agencies should be designed, to make sure the mechanical devices operate with safety.

1. VH Series PLC Introductions

| Item | Specifications |
|-----------------------------|--|
| Work Ambient Temperature | 0~55°C / 32~131°F |
| Storage Ambient Temperature | -20~70°C / -4~158°F |
| Work Ambient Humidity | 10~90% RH, (at 25°C / 77°F, no condensation) |
| Storage Ambient Humidity | 10~90% RH, (at 25°C / 77°F, no condensation) |
| Vibration Tolerance | 10~55 Hz with amplitude of 0.075 mm / 0.30 inch and acceleration along X, Y and Z axes each for 80 min (8 min/Cycle × 10 times = 80 min) at 55 ~ 150 Hz with 1G. |
| Shock Tolerance | 10 G along X, Y and Z axes each for three times |
| Noise Immunity | Noise Simulator 1500 Vp-p, 1μS Pulse Width and 25~60Hz Frequency |
| Dielectric Strength | 1500VAC 1 min between AC terminal and rack panel or 500VAC 1 min between DC terminal and rack panel |
| Insulation Resistance | 5 MΩ or above at DC 500V between AC terminal and rack panel |
| Grounding | Class-3 Grounding (DO NOT ground with major power supply equipment.) ※ |
| Environmental Condition | Keep away from corrosive gas or excessive dust. |



1. VH Series PLC Introductions

1-7 Performance Specification

| Item | | Specifications | |
|----------------------------|----------------------------|--|------------------------------|
| Operation Control Method | | Cyclic Operation by Stored Program | |
| Programming Language | | Electric Ladder Diagram + SFC | |
| I/O Control Method | | Batch Processing | |
| Operation Processing Rate | Basic Instruction | 0.375~12.56 μ s | |
| | Applied Instruction | Several μ s ~ Several hundreds of μ s | |
| Number of Instructions | Basic Instruction | 27 (including LDP, LDF, ANDP, ANDF, ORP, ORF, INV) | |
| | Stepladder Instructions | 2 | |
| | Applied Instructions | 73 | |
| Memory Capacity | Program Capacity | Built-in 4 K Steps Flash ROM | |
| | Component Comment Capacity | 2730 comments (16 characters or 8 double-byte characters for each) | |
| | Program Comment Capacity | 20,000 characters or 10,000 double-byte characters | |
| Max. Input / Output Points | | 128 points: X0 ~ X77, Y0 ~ Y77 | |
| Internal Relay | Auxiliary Relay (M) | General | 384 points: M0 ~ M383 |
| | | Latched | 128 points: M384 ~ M511 |
| | | Special | 256 points: M9000 ~ M9255 |
| | State Relay (S) | Initial | 10 points: S0 ~ S9 (Latched) |
| | | Latched | 118 points: S10 ~ S127 |
| Timer (T) | 100mS | 63 pts when M9028 OFF: T0 ~ T62 (Timer range: 0.1 ~ 3276.7 sec.) | |
| | 10mS | 31 pts when M9028 ON: T32 ~ T62 (Timer range: 0.01 ~ 327.67 sec.) | |
| | 1mS | 1 point: T63 (Timer range: 0.001 ~ 32.767 sec.) | |
| Counter (C) | 16-bit Up | General | 16 points: C0 ~ C15 |
| | | Latched | 16 points: C16 ~ C31 |

1. VH Series PLC Introductions

| Item | | Specifications | |
|---|-------------------------|--|--|
| High Speed Counter (C) | 32-bit Up/Down, Latched | 1-phase Counter | 11 points: C235 ~ C245 (Signal Frequency: 10 kHz Max.) |
| | | 2-phase Counter | 5 points: C246 ~ C250 (Signal Frequency: 10 kHz Max.) |
| | | A/B Phase Counter | 4 points: C251 ~ C254 (Signal Frequency: 5 kHz Max.) |
| Data Register (D) | | General | 128 points: D0 ~ D127 |
| | | Latched | 128 points: D128 ~ D255 |
| | | Special | 256 points: D9000 ~ D9255 |
| | | Index | 16 points: V0 ~ V7, Z0 ~ Z7 |
| Pointer | | Call Pointer (P) | 64 points: P0 ~ P63 |
| | | Interrupt Pointer (I) | 15 points: 6 points for external interrupt, 3 points for timer interrupt, and 6 points for counter interrupt |
| | | Nest Pointer (N) | 8 points: N0 ~ N7 |
| Constants Range | Decimal (K) | 16 Bits | -32768 ~ 32767 |
| | | 32 Bits | -2147483648 ~ 2147483647 |
| | Hexadecimal (H) | 16 Bits | 0H ~ FFFFH |
| | | 32 Bits | 0H ~ FFFFFFFFH |
| Pulse Output | | 1 point, Max. 7 kHz | |
| Programming Device Link Interface CP1 | | RS-232C, can connect to PC, HMI or MODEM directly. | |
| Communication Link Interface CP2 (Optional) | | RS-232C or RS-422 / RS-485, can connect to PC or HMI | |
| Communication Link Interface CP3 (Optional) | | RS-485, can connect to PC or HMI | |
| Real Time Clock (Optional) | | Displays year, month, day, hour, min., sec. and week | |
| Error Code Display Function | | Displays 109 error codes (01~99 and E0~E9) | |

1. VH Series PLC Introductions

1-8 Instruction Tables

Basic Instruction Table

| Inst. | Function | Devices | Inst. | Function | Devices |
|-------|---|-----------------------|-------|--------------------------------------|-----------------------|
| LD | Initial logical operation A contact | X · Y · M · S · T · C | MC | Start of a master control block | N0~N7 |
| LDI | Initial logical operation B contact | X · Y · M · S · T · C | MCR | End of a master control block | N0~N7 |
| AND | Serial link of NO contacts | X · Y · M · S · T · C | MPS | Stores current internal opr. Result | — |
| ANI | Serial link of NC contacts | X · Y · M · S · T · C | MRD | Reads current internal opr. Result | — |
| OR | Parallel link of NO contacts | X · Y · M · S · T · C | MPP | Pops currently stored result | — |
| ORI | Parallel link of NC contacts | X · Y · M · S · T · C | NOP | No operation or null step | — |
| ANB | Serial link of multi. parallel circuits | — | END | Force current prog. scan to end | — |
| ORB | Paral. link of multi. contact circuits | — | LDP | Init. logical opr. rising edge pulse | X · Y · M · S · T · C |
| OUT | Final logical op. type coil drive | Y · M · S · T · C | LDF | Init. logical opr. fall. edge pulse | X · Y · M · S · T · C |
| SET | Sets component permanently ON | Y · M · S | ANDP | Serial link of rising edge pulse | X · Y · M · S · T · C |
| RST | Resets comp. permanently OFF | Y · M · S · T · C · D | ANDF | Serial link of falling edge pulse | X · Y · M · S · T · C |
| PLS | Rising edge pulse | Y · M | ORP | Paral. link of rising edge pulse | X · Y · M · S · T · C |
| PLF | Falling/trailing edge pulse | Y · M | ORF | Paral. link of falling edge pulse | X · Y · M · S · T · C |
| | | | INV | Invert current internal opr. result | — |

Stepladder Instruction Table

| Instruction | Function | Devices |
|-------------|--------------------------|---------|
| STL | Initiation of Stepladder | S |
| RET | End of Stepladder | — |

1. VH Series PLC Introductions

Extension Unit Model Numbering

| Type | FNC NO. | Title* | | Function |
|------------------|---------|--------|--------|--------------------------------|
| | | D | P | |
| Program Flow | 00 | | CJ P | Conditional Jump |
| | 01 | | CALL P | CALL subroutine |
| | 02 | | SRET | Subroutine RETurn |
| | 03 | | IRET | Interrupt RETurn |
| | 04 | | EI | Enable Interrupt |
| | 05 | | DI | Disable Interrupt |
| | 06 | | FEND | First END |
| | 07 | | WDT P | Watch Dog Timer refresh |
| | 08 | | FOR | Start of a FOR-NEXT loop |
| | 09 | | NEXT | End of a FOR-NEXT loop |
| Compare and Move | 10 | D | CMP P | CoMPare |
| | 11 | D | ZCP P | Zone ComPare |
| | 12 | D | MOV P | Move |
| | 13 | | SMOV P | Shift MOVE |
| | 14 | D | CML P | CoMpLiment |
| | 15 | | BMOV P | Block MOVE $n \rightarrow n$ |
| | 16 | D | FMOV P | Fill MOVE $1 \rightarrow n$ |
| | 17 | D | XCH P | EXCHange |
| | 18 | D | BCD P | Converts BIN \rightarrow BCD |
| | 19 | D | BIN P | Converts BCD \rightarrow BIN |

| Type | FNC NO. | Title* | | Function | |
|-----------------------------------|---------|--------|--------|-----------------------------|--|
| | | D | P | | |
| Arithmetic and Logical Operations | 20 | D | ADD P | ADDition | |
| | 21 | D | SUB P | SUBtraction | |
| | 22 | D | MUL P | MULtiplication | |
| | 23 | D | DIV P | DIVision | |
| | 24 | D | INC P | INCrement | |
| | 25 | D | DEC P | DECrement | |
| | 26 | D | WAND P | Logic Word AND | |
| | 27 | D | WOR P | Logic Word OR | |
| | 28 | D | WXOR P | Logic Word eXclusive OR | |
| | | | | | |
| Rotary and Shift | 30 | D | ROR P | ROtation Right | |
| | 31 | D | ROL P | ROtation Left | |
| | 32 | D | RCR P | Rotation Right with Carry | |
| | 33 | D | RCL P | Rotation Left with Carry | |
| | 34 | | SFTR P | Bit ShiFT Right | |
| | 35 | | SFTL P | Bit ShiFT Left | |
| | 38 | | SFWR P | ShiFt register WRite (FIFO) | |
| | 39 | | SFRD P | ShiFt register ReaD (FIFO) | |
| | | | | | |
| | | | | | |

1. VH Series PLC Introductions

| Type | FNC NO. | Title* | | Function |
|-----------------------|---------|--------|--------|----------------------------|
| | | D | P | |
| Processing | 40 | | ZRST P | Zone ReSeT |
| | 41 | | DECO P | DECOde |
| | 42 | | ENCO P | ENCOde |
| High-speed Processing | 50 | | REF P | REFresh I/O |
| | 53 | D | HSCS | High Speed Counter Set |
| | 54 | D | HSCR | High Speed Counter Reset |
| | 56 | | SPD | SPEed Detection |
| | 57 | D | PLSY | PuLSe Y output |
| | 58 | | PWM | Pulse Width Modulation |
| Handy Instruction | 62 | D | ABSD | ABSolute Drum sequencer |
| | 63 | | INCD | INCremental Drum sequencer |
| | 66 | | ALT P | ALTErnate state |
| | 67 | | RAMP | RAMP variable value |
| Others | 73 | | SEGD P | Seven SEGment Decoder |
| | 167 | | TWR P | Time WRites to RTC |
| | 176 | | TFT | Timer (10 ms) |
| | 177 | | TFH | Timer (100 ms) |
| | 178 | | TFK | Timer (1 sec.) |

| Type | FNC NO. | Title* | | Function |
|---------------------|---------|--------|---------------------|-----------------------|
| | | D | P | |
| In-line Comparisons | 224 | D | LD = | LoaD when (S1) = (S2) |
| | 225 | D | LD > | LoaD when (S1) > (S2) |
| | 226 | D | LD < | LoaD when (S1) < (S2) |
| | 228 | D | LD < > | LoaD when (S1) ≠ (S2) |
| | 229 | D | LD ≤ | LoaD when (S1) ≤ (S2) |
| | 230 | D | LD ≥ | LoaD when (S1) ≥ (S2) |
| | 232 | D | AND = | AND when (S1) = (S2) |
| | 233 | D | AND > | AND when (S1) > (S2) |
| | 234 | D | AND < | AND when (S1) < (S2) |
| | 236 | D | AND < > | AND when (S1) ≠ (S2) |
| | 237 | D | AND ≤ | AND when (S1) ≤ (S2) |
| | 238 | D | AND ≥ | AND when (S1) ≥ (S2) |
| | 240 | D | OR = | OR when (S1) = (S2) |
| | 241 | D | OR > | OR when (S1) > (S2) |
| | 242 | D | OR < | OR when (S1) < (S2) |
| | 244 | D | OR < > | OR when (S1) ≠ (S2) |
| 245 | D | OR ≤ | OR when (S1) ≤ (S2) | |
| 246 | D | OR ≥ | OR when (S1) ≥ (S2) | |

1-9 Special Components and Error Messages

In the tables below, the symbol "■" represents that the component cannot be driven by instructions and no data can be written into it. And for any component that is not listed below, it is reserved for system use, and cannot be driven by instructions and no data can be written into either.

| Coil No. | Function |
|-----------------------|--|
| PLC Operation Status. | |
| ■ M9000 | Always-ON A Contact during RUN period |
| ■ M9001 | Always-OFF A Contact during RUN period |
| ■ M9002 | Initial Pulse A Contact, ON for a scan time |
| ■ M9003 | Initial Pulse B Contact, OFF for a scan time |
| ■ M9004 | Error occurs |
| Clock Pulse | |
| ■ M9011 | 10ms cycles pulse. ON 5ms/OFF 5ms |
| ■ M9012 | 100ms cycles pulse. ON 50ms/OFF 50ms |
| ■ M9013 | 1sec. cycles pulse. ON 0.5Sec/OFF 0.5Sec |
| ■ M9014 | 1min. cycles pulse. ON 30Sec/OFF 30Sec |
| System Status | |
| ■ M9005 | ON when battery of the RTC is low |
| ■ M9018 | ON when RTC installed in the Main Unit |
| M9028 | OFF T32~T62 become 100ms counter |
| | ON T32~T62 become 10ms counter |
| M9031 | Clear the Non-Latched area memory |
| M9032 | Clear the Latched area memory |
| M9033 | Not clear data memory when RUN → STOP. |

| Coil No. | Function |
|---|---|
| System Status | |
| M9034 | All the outputs are disabled |
| M9039 | Constant Scan Time set by D9039 |
| Flag | |
| ■ M9020 | Zero Flag. Result of ADD or SUB is "0" |
| ■ M9021 | Borrow Flag. Borrow occurred to ADD or SUB |
| M9022 | Carry Flag. Carry occurred to ADD or SUB |
| ■ M9029 | Execution complete flag for some instructions |
| Assigned Operation Mode of Applied Instructions | |
| M9024 | Assign BMOV moving directions |
| M9025 | Assign external HSC reset mode |
| M9026 | Assign RAMP hold mode |
| M9168 | Assign SMOV operation mode |
| Stepladder Instruction Flags | |
| M9040 | Step Ladder move prevented |
| ■ M9046 | STL step is working |
| M9047 | STL monitoring is enabled |
| | |
| | |

1. VH Series PLC Introductions

| Coil No. | Function |
|---|---|
| Interrupt Prevented | |
| M9050 | Input interrupt I00□ is prevented. |
| M9051 | Input interrupt I10□ is prevented. |
| M9052 | Input interrupt I20□ is prevented. |
| M9053 | Input interrupt I30□ is prevented. |
| M9054 | Input interrupt I40□ is prevented. |
| M9055 | Input interrupt I50□ is prevented. |
| M9056 | Input interrupt I6□□ is prevented. |
| M9057 | Input interrupt I7□□ is prevented. |
| M9058 | Input interrupt I8□□ is prevented. |
| M9059 | HSCounter interrupt I010~I060 disallow |
| Error Message | |
| ■M9019 | Real Time Clock setting error. |
| ■M9066 | Program CHECK SUM error. |
| ■M9067 | Operation error. PLC will keep running. |
| M9068 | IOperation error latch. |
| Control and Monitor High Speed Counter Count. Direction | |
| ■M9235 ? | When M92□□="OFF", C2□□ is up counter |
| ■M9245 | When M92□□="ON", C2□□ is down counter |
| ■M9246 ? | When C2□□ is up counter, M92□□=OFF |
| ■M9254 | When C2□□ is down counter, M92□□=ON |

Table for Special Registers

| Coil No. | Function |
|----------------------|--|
| PLC Operation Status | |
| D9000 | Time Setting of Watch Dog Timer. (unit: 1ms) |
| ■D9004 | Error coil ID shows the source of the error. |
| ■D9010 | Current operation scan time (unit: 1ms) |
| ■D9011 | Min. scan time (unit: 1ms) |
| ■D9012 | Max. scan time (unit: 1ms) |
| System Status | |
| ■D9001 | Displays the PLC model and version. (※1) |
| ■D9002 | Capacity size of Memory. 2 for 2000 steps. |
| ■D9003 | Type of Memory. (※2) |
| D9020 | X0~X7 input response time setting: 0~15ms. |
| D9039 | Constant Scan Time setting. |
| Real Time Clock Data | |
| D9013 | Second value. (0~59) |
| D9014 | Minute value. (0~59) |
| D9015 | Hour value. (0~23) |
| D9016 | Day value. (1~31) |
| D9017 | Month value. (1~12) |
| D9018 | Year value: 2000~YYYY (4 digits) |
| D9019 | Weekday value: 0 (Sun.) ~ 6 (Sat.) |
| | |
| | |

1. VH Series PLC Introductions

| Coil No. | Function | | |
|-------------------------------------|---|--|-------------------------|
| Step Ladder Instructions | | | |
| ■ D9040 | 1 st active STL step | When M9047 ON, the step point ID which are in action is stored in D9040~D9047. Where the smallest one is stored in D9040, the second smallest one is stored in D9041 and so forth. | |
| ■ D9041 | 2 nd active STL step | | |
| ■ D9042 | 3 rd active STL step | | |
| ■ D9043 | 4 th active STL step | | |
| ■ D9044 | 5 th active STL step | | |
| ■ D9045 | 6 th active STL step | | |
| ■ D9046 | 7 th active STL step | | |
| ■ D9047 | 8 th active STL step | | |
| Error Message | | | |
| ■ D9067 | Error code identifying Operation error. | | |
| D9068 | Latched the step address number of opr. Error | | |
| ■ D9069 | Step address number of Operation error. | | |
| Multi-Functional Error Code Display | | | |
| D9080 | Control Display | 0 | Displays the I/O Status |
| | | 1~99 | Displays 1~99 |
| | | 100~109 | Displays E0~E9 |
| High Speed Process Instruction | | | |
| ■ D9136 | Lower 16 bits | Total number of output pulses using PLSY instruction. | |
| ■ D9137 | Higher 16 bits | | |
| ■ D9140 | Lower 16 bits | Total number of output pulses using PLSY instruction. | |
| ■ D9141 | Higher 16 bits | | |

| Coil No. | Function | |
|---------------------|-------------------|--|
| Index Register V, Z | | |
| D9180 | Z0 Index Register | |
| D9181 | V0 Index Register | |
| D9182 | Z1 Index Register | |
| D9183 | V1 Index Register | |
| D9184 | Z2 Index Register | |
| D9185 | V2 Index Register | |
| D9186 | Z3 Index Register | |
| D9187 | V3 Index Register | |
| D9188 | Z4 Index Register | |
| D9189 | V4 Index Register | |
| D9190 | Z5 Index Register | |
| D9191 | V5 Index Register | |
| D9192 | Z6 Index Register | |
| D9193 | V6 Index Register | |
| D9194 | Z7 Index Register | |
| D9195 | V7 Index Register | |

※1

| | | | | |
|---|---|---|---|---|
| 2 | 1 | 1 | 0 | 0 |
|---|---|---|---|---|

Version: V1.00

Model: VH Series

※2 00H indicates a built-in Flash Memory of PLC.
01H indicates an expanded VB-MP1R Memory Card.






1. VH Series PLC Introductions

Error Message Specifications





Operation Error Code (the value of D9067)

| Error Code | Detail |
|------------|---|
| 0 | No Error |
| 6702 | More than 5 layers of Call instruction have been nested together. |
| 6703 | More than 2 layers of Interrupt Insert have been nested together. |
| 6704 | More than 5 layers FOR / NEXT have been nested together. |
| 6705 | Incompatible device assigned as operand of applied instruction. |
| 6706 | Allowable range of applied instruction operand exceeded. |










1-10 Terminal Layouts



1. VH Series PLC Introductions



1. VH Series PLC Introductions



1. VH Series PLC Introductions

1-11 Product List

| Item | Model | Main Specification |
|----------------------|----------|--|
| Main Unit | VH-10MR | DC 24V Power, 6 points DC24V Input, 4 points Relay Output |
| | VH-14MR | DC 24V Power, 8 points DC24V Input, 6 points Relay Output |
| | VH-20MR | AC Power, 12 points DC24V Input, 8 points Relay Output, provide DC24V Output 420mA |
| | VH-24MR | AC Power, 14 points DC24V Input, 10 points Relay Output, provide DC24V Output 420mA |
| | VH-28MR | AC Power, 16 points DC24V Input, 12 points Relay Output, provide DC24V Output 420mA |
| | VH-32MR | AC Power, 16 points DC24V Input, 16 points Relay Output, provide DC24V Output 420mA |
| | VH-40MR | AC Power, 24 points DC24V Input, 16 points Relay Output, provide DC24V Output 420mA |
| | VH-60MR | AC Power, 36 points DC24V Input, 24 points Relay Output, provide DC24V Output 420mA |
| Extension Unit | VH-32ER | AC Power, 16 points DC24V Input, 16 points Relay Output, provide DC24V Output 420mA |
| Extension Module | VH-28XYR | 20 points DC24V Input, 8 points Relay Output |
| | VH-16XYR | 8 points DC24V Input, 8 points Relay Output |
| | VH-16X | 16 points DC24V Input |
| | VH-8XYR | 4 points DC24V Input, 4 points Relay Output |
| | VH-8X | 8 points DC24V Input |
| | VH-8YR | 8 points Relay Output |
| Communication Module | VB-485A | RS-485 Communication Module; Photocoupler Isolated; Max. Distance: 1000M/3280' |
| | VB-CADP | One Isolated RS-232 / RS-485 Port and one Isolated RS-485 Port; Max. Distance: 1000M/3280' |
| Connection Cables | VB-232 | RS-232C Communication Expansion Card |
| | VB-485 | RS-422 / RS-485 Communication Expansion Card; non-Isolated; Max. Distance: 50M/164' |
| Power Supplier | VB-MP1R | Flash ROM Program Memory Card (4K Steps for the VH series PLC); including the RTC (Real Time Clock) function |
| | VB-RTC | RTC (Real Time Clock) Expansion Card |


1. VH Series PLC Introductions

| Item | Model | Main Specification |
|-------------------|-------------|---|
| Connection Cables | MWPC-200 | Cable between a PLC (CP1 A-type USB) and Computer (9-pin female connector); Length: 200cm/6'7" |
| | MWMD-200 | Cable between a PLC (CP1 A-type USB) and MODEM (9-pin male connector) with a length of 200cm/6'7" |
| | MWPC25-200 | Cable between a PLC (CP1 A-type USB) and Computer (25-pin female connector); Length: 200cm/6'7" |
| | VBPC09-200 | Cable between a PLC (CP1 JST 4P) and Computer (9-pin female connector); Length: 200cm/6'7" |
| | VBMD09-200 | Cable between a PLC (Cp1 JST 4P) and MODEM (9-pin male connector); Length: 200cm/6'7" |
| | VBPC25-200 | Cable between a PLC (CP1 JST 4P) and Computer (25-pin female connector); Length: 200cm/6'7" |
| | VBFDHMI-200 | Cable between a PLC (CP1 JST 4P) and Fuji, Digital HMI (25-pin male D-SUB); Length: 200cm/6'7" |
| | VHEC-050 | VH Series PLC Expansion Extended cable; Length: 50cm/19.7" |
| Power Supplier | VB-30PS | 30W power supply; power input: AC 110V or AC 220V; outputs: DC 24V 1.2A and DC 5V 0.2A |


※ The VH-10/14MR Main Units do not have communication expansion slot, memory card slot and the I/O extension slot.

1. VH Series PLC Introductions


1-12 Dimensions



Main Unit/Extension Unit



Main Unit/Extension Module



| Model | Weight (kg) |
|---------|-------------|
| VH-10MR | 0.31 |
| VH-14MR | 0.32 |
| VH-20MR | 0.56 |
| VH-24MR | 0.57 |
| VH-28MR | 0.57 |

| Model | Weight (kg) |
|----------|-------------|
| VH-32MR | 0.57 |
| VH-40MR | 0.77 |
| VH-60MR | 0.91 |
| VH-32ER | 0.54 |
| VH-16XYR | 0.29 |

| Model | Weight (kg) |
|----------|-------------|
| VH-16X | 0.26 |
| VH-8XYR | 0.26 |
| VH-8X | 0.29 |
| VH-8YR | 0.27 |
| VH-28XYR | 0.34 |

Installation Safety Guidelines




CAUTION

- The product should be used under certain conditions as stated in “1-6 General Specifications” of this manual.
- The product should NOT be used under the following conditions:
 - (1) Excessive or conductive dust, corrosive or flam. gas, or oily smoke.
 - (2) Excessive heat, moisture or rain, condensation, regular impact shocks or excessive vibration. The above-mentioned conditions may cause electric shock, fire or misoperation and damage the product.
- Take special care not to allow debris to fall inside the unit during installation e.g. making screw holes, cut wires etc, for it may cause fire, product damage or mis-reaction.
- Once the installation is complete, remove the protective paper band on the PLC to prevent fire, product damage or mis-reaction caused by the overheating.
- Install the connection cables and expansion modules properly, and make sure they are fixed, for loose contact may cause mis-reaction.
- DO NOT install the product on the basement, top or along the vertical direction of a switchboard, to avoid overheating.
- Ensure that there is a space larger than 50 mm around the installed PLC and it is kept as far as possible from high-voltage cables, high-voltage equipment and power equipment.

2. Installation Work


2-1 Installation Guides

• DIN Rail Installation



Install the product on the 35mm DIN rail handle. Pull down the handle when un-install to take the product off.


• Direct Installation



Pull out the 2 hidden mounting hole s (100mm between) from the top and bottom of the product, and install with screws.

2-2 Wiring Guidelines

- DO NOT pass PLC's Input Signal and Output signal through the same cable.
- DO NOT tie the Input Signal cable/Output Signal Cable together with other power cables.
- Limit the cable length to be within 20 meters for safety reasons.
- Use O or Y type terminal when wiring as specified on the right hand side diagram.
- Tighten the screw properly to avoid misoperation. The proper strength used to turn the terminal screw is 5~8kg-cm.



Wiring Safety Guidelines



DANGER

- Cut all the external power during installation or wiring, to avoid electric shock or product damage.
- Close the terminal cover before switch on the power supply after installation or wiring, to avoid electric shock.

Wiring Safety Guidelines



CAUTION

- When wiring AC supplies, it must be connected to correct input terminal, for if it is connected to DC (Direct Current) input/output terminal or DC power terminal, the PLC will be damaged.
- DO NOT connect the 24 V OUT \oplus terminal of a PLC main unit to the 24 V OUT \oplus terminal of an extension unit, or to the \oplus terminal of an external power supply, for it may damage the PLC.
- DO NOT do any external wiring for the empty terminals of a PLC, for it may damage the product.
- Connect the grounding terminal of the main unit using the class 3 grounding standard, but DO NOT ground it with major power systems. (Refer to 1-6)

3. Power Specifications and External Wiring


3-1 Power Specifications

Power Specifications (Including All VH Series Main Units and Extension Units)

| Item | AC Power | DC Power |
|---|---|-------------------|
| Input Voltage | AC100 ~ 240V +10% / -15% | DC24V +20% / -15% |
| Input Frequency | 50/60Hz | — |
| Max. allowable momentary power failure period | Within 10 ms. | Within 1 ms. |
| Power Fuse | 250V 2A | 250V 0.5A |
| Power Consumption | 30 VA | 5W |
| Power Unit Output Current | DC5V 400mA | — |
| | DC12V 530mA | — |
| | DC24V \pm 15% 420mA; output from terminal | — |

3. Power Specifications and External Wiring

3-2 AC Power Wiring Example




CAUTION

- 24V OUT can be used as sensor power but DO NOT send external power to it.
- DO NOT do external wiring for any empty terminal or use it as a relay terminal.
- DO NOT connect the positive terminal of the Main Unit and Extension Unit together, but please connect their negative terminals together.

3. Power Specifications and External Wiring

3-3 DC Power Wiring Example



- Connect the 24V IN terminal of the Main Unit with Direct Current power of DC 24V 15%/+20%.
- Try to use Constant Voltage Power Supply if possible. Make sure a Wave Filter Capacitor is used if need to use a full-wave Rectifying Power Supply
- DO NOT do external wiring for any empty terminal or use it as a relay terminal.

Wiring Safety Guidelines



CAUTION

- When wiring AC supplies, it must be connected to correct input terminal, for if it is connected to DC (Direct Current) input/output terminal or DC power terminal, the PLC will be damaged.
- DO NOT connect the 24 V OUT ⊕ terminal of a PLC main unit to the 24 V OUT ⊕ terminal of an extension unit, or to the ⊕ terminal of an external power supply, for it may damage the PLC.
- DO NOT do any external wiring for the empty terminals of a PLC, for it may damage the product.
- Connect the grounding terminal of the main unit using the class 3 grounding standard, but DO NOT ground it with major power systems. (Refer to 1-6)

4. Input Specifications and External Wiring


4-1 Input Point Specifications

| Item | Specification |
|--------------------------|--|
| Input Activating Voltage | DC24V \pm 15% |
| Input Signal Circuit | 7 mA / DC 24V |
| Input ON Circuit | Above 3.5 mA |
| Input OFF Circuit | Below 1.7 mA |
| Input Resistance | 3.3 K Ω approximately |
| Input Response Time | 10 ms approximately, X0~X7 can be set to be 0~15 ms by changing the value of D9020. |
| Input Signal Type | Dry Contact or NPN open collector transistor |
| Isolation Mode | Photocoupler Isolation |
| Circuit Diagram | <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>AC Power Model</p> </div> <div style="text-align: center;"> <p>DC Power Model</p> </div> </div> |


4. Input Specifications and External Wiring

4-2 Input Point Wiring Introduction


- Input Point Wiring Example



- "Sensor Power Provided by PLC" Wiring Method




- "Sensor Power Provided by External Source" Wiring Method



4. Input Specifications and External Wiring


4-3 Input Wiring Notes

- The input point current of this product is 7mA/DC24V. So please choose a mini switch as input device, which suits such micro-current. Loose contact problem may occur if macro-current switch is used.
- Keep the voltage drop below 4V approximately if serial diode string is used in the input circuit, as shown in the right hand side diagram.




- Make sure the Parallel Resistor has more than 15KΩ Rp if used in the input circuit, as shown in the diagram below. And if the resistor Rp is less than 15KΩ, please install a pull up resistor Rb.

$$R_b \leq \frac{4R_p}{15 - R_p} \text{ (K}\Omega\text{)}$$



- Install a pull up resistor Rb if the OFF current leakage of the 2-wire-close-contact switch used is more than 1.5mA, as shown in the diagram below.

$$R_b \leq \frac{6}{I \text{ (OFF Current Leakage)} - 1.5} \text{ (K}\Omega\text{)}$$



4. Input Specifications and External Wiring

4-4 About the X0~X7 Input Points

There are 8 input points (X0~X7) in the VH Series Main Unit. These 8 points have high speed input function such as High Speed Counter, External Interrupt Insertion and Speed Detection, etc. When X0~X7 are not used as high speed inputs, they can still be used as common input points.

The corresponding relations of X0~X7 input terminals and their high speed applications are listed below:

| In/Out | 1-Phase Counter | | | | | | | | | | 2-Phases Counter | | | | | A/B-Phase Counter | | | | External Interrupt Insertion | Speed Detect | |
|--------|-----------------|------|------|------|------|------|------|------|------|------|------------------|------|------|------|------|-------------------|------|------|------|------------------------------|--------------|------|
| | C235 | C236 | C237 | C238 | C239 | C240 | C241 | C242 | C243 | C244 | C245 | C246 | C247 | C248 | C249 | C250 | C251 | C252 | C253 | | | C254 |
| X0 | U/D | | | | | | U/D | | | U/D | | U | U | | U | | A | A | | A | I00□ | ○ |
| X1 | | U/D | | | | | R | | | R | | D | D | | D | | B | B | | B | I10□ | ○ |
| X2 | | | U/D | | | | U/D | | | U/D | | R | | R | | | | R | | R | I20□ | ○ |
| X3 | | | | U/D | | | R | | | R | | | | U | | U | | | A | | I30□ | ○ |
| X4 | | | | | U/D | | | | U/D | | | | | D | | D | | | B | | I40□ | ○ |
| X5 | | | | | | U/D | | | R | | | | | R | | R | | | R | | I50□ | ○ |
| X6 | | | | | | | | | | S | | | | | S | | | | S | | | |
| X7 | | | | | | | | | | S | | | | | S | | | | | | | |

U: Up Counter Input; D: Down Counter input; A: A-Phase Counter Input; B: B-Phase Counter Input
 U/D: Up / Down Count Input; R: Reset Counter Input; S: Start-up Counter Input

- X0~X7 cannot be repeatedly used. Each point can only choose 1 function from table above to execute.
- All high speed input function can complete the counting by interrupt insertion, and the total frequency of the interrupt inserting should not be more than 20KHz.

Calculation Method of the Total Interrupt Insertion Frequency

(Total of 1-Phase Counter Frequency) + (Total of 2-Phases Counter Frequency) +
 (Total of A/B-Phase Counter Frequency x 2) + Input Pulse Frequency of Speed Detection (SPD)
 Instruction = Total Frequency of Interrupt Insertion *This value should not be more than 20KHz.

5. Output Specifications and External Wiring

Design Safety Guidelines



DANGER

- External protective circuits should be designed for a PLC to avoid mechanical damage. E.g. Emergency Stop, Forward/Reverse Inter-Lock or Upper/Lower Limit Positioning.
- A PLC may not be able to control the ON/OFF state when error occurs to its output relay and transistor, etc. So for crucial output signals which could cause major accident, some external safety circuit and agencies should be designed, to make sure the mechanical devices operate with safety.

Wiring Safety Guidelines




CAUTION

- When wiring AC supplies, it must be connected to correct input terminal, for if it is connected to DC (Direct Current) input/output terminal or DC power terminal, the PLC will be damaged.
- DO NOT connect the 24 V OUT ⊕ terminal of a PLC main unit to the 24 V OUT ⊕ terminal of an extension unit, or to the ⊕ terminal of an external power supply, for it may damage the PLC.
- DO NOT do any external wiring for the empty terminals □ of a PLC, for it may damage the product.
- Connect the grounding terminal of the main unit using the class 3 grounding standard, but DO NOT ground it with major power systems. (Refer to 1-6)

5. Output Specifications and External Wiring


5-1 Output Point Specifications

| Item | Specification | |
|----------------------|---|-------------------------------|
| Output Type | Relay Output | |
| Switched Voltages | \leq AC 250V / DC 30V | |
| Rated Current | Resistive Load | 2 A /point, 8 A /4 points COM |
| | Inductive Load | 80VA |
| | Lamp Load | 100W |
| Open Circuit Leakage | — | |
| Output Response Time | 10 ms approximately | |
| Isolation Method | Mechanic Isolation | |
| Circuit Diagram |  | |


5. Output Specifications and External Wiring

5-2 Output Wiring Introduction

- Relay Output Wiring Diagram



- ① AC Power Supply
- ② Fuse (※)
- ③ Inductive Load
- ④ Incandescent Light Bulb
- ⑤ Neon Bulb
- ⑥ Contactor
- ⑦ Spark Killer
- ⑧ DC Power






- ③ Inductive Load
- ⑥ Contactor
- ⑧ DC Power
- ⑨ Light Emitting Diode LED
- ⑩ Surge Protective Diode

※ No fuse installed within the PLC's internal output circuit. Please install external fuse to avoid board circuit damage caused by short circuit of the load.
Install 2~3A fuse for single point COM circuit.
Install 5~10A fuse for 4 points COM circuit.

5. Output Specifications and External Wiring

5-3 Output Wiring Notes

- Please add parallel connected Surge Protective Diode to the 2 ends of the DC Inductive Load, as shown in the right hand side diagram, otherwise the pointer life time will be reduced significantly. When choose the Surge Protective Diode, note that the reverse voltage (VR) must be more than 5~10 times of the forward voltage (FR), and the forward current (IF) must be greater than the load current.
- Please add parallel connected Spark Killer to the 2 ends of the AC Inductive Load, as shown in the right hand side diagram, to reduce noise. A Spark Killer is made by serial connected resistor and capacitor ($0.1\mu\text{F} + 120\Omega$), and can be purchased from the producer.
- IT IS DANGEROUS to close the contactors used as the forward (FP)/reverse (RP) control at the same time. For such a load, an external inter-lock circuit should be set up as well as the inter-lock that controlled by the program within the PLC, as demonstrated in the right hand side diagram.




5. Output Specifications and External Wiring

5-4 About the Y0 Output Point

The Y0 output point of VH series PLC has high speed output functions like pulse output, Pulse Width Modulation, etc. Y0 can be used as general output point when it is not used for high speed output.

- Use transistor output form for the output when Y0 used as high speed output point.
- The output point assigned by PLSY and PWM should not overlap with each other.
- The pulse frequency sent by Y0 of VH series PLC using PLSY instruction can be 7KHz at most.
- Since the PLSY and PWM instructions output need to have high speed reaction, please connect a parallel Rb resistor as demonstrated in the right hand side diagram and make the total load current to be 100 mA approximately, for the PLC output wave shape will be twisted by the longer OFF time of the transistor under light load. Calculate the power needed by the Rb resistor carefully, to avoid Rb resistor damage caused by overheats.



| External Power | 50mA Rb of the Load Current | 100mA Rb of the Load Current |
|----------------|-----------------------------|------------------------------|
| 5V | 100Ω 1W | 50Ω 2W |
| 12V | 240Ω 2W | 120Ω 3W |
| 24V | 480Ω 3W | 240Ω 5W |

6-1 Models of Optional Modules

The optional modules of VH series PLC are listed in the table below:

| Slot | Model | Function |
|------------------------------|---------|---|
| Communication Expansion Slot | VB-232 | RS-232 Communication Expansion Card, extend the second communication port (CP2) |
| | VB-485 | RS-422/RS-485 Communication Expansion Card, extend the second communication port (CP2) |
| Memory Card Expansion Slot | VB-RTC | <ul style="list-style-type: none"> ● Install the RTC (Real Time Clock) Expansion Card for PLC, to do automatic Date and Time control. ● Displays Year, Month, Day, Hour, Minute, Second and Week. ● Battery life is 5 years approximately @ 25°C. ● The special register M9005 will turn ON when the battery is running out of power. |
| | VB-MP1R | <ul style="list-style-type: none"> ● A memory card used by the VH and VB series PLC, to record program, component comments, program comments and data registers. ● Flash ROM Memory that can be written for more than 10,000 times. ● The program downloading/uploading function makes the program copy and device maintenance work easier. ● Built-in RTC (Real Time Clock) function, battery life is 5 years approximately @ 25°C. ● The special register M9005 will turn ON when the battery is running out of power. |

※ The VH-10/14 MR Main Unit does not have communication expansion or memory card expansion slot.

6. Optional Modules


6-2 Communication Expansion Board

- VB-232 and VB-485 are the expansion cards for VH series PLC's second communication port (CP2).
- The second communication port of VH series PLC can execute Computer Link communication functions.
- Please install the communication expansion board when the power supply is OFF.

Install VB-232




- ① Switch off the PLC power
- ② Open the left side cover of the PLC Main Unit.
- ③ Take off the black screw in the upper left corner inside the left cover.
- ④ Install the base plug of VB-232 into the communication expansion slot.
- ⑤ Install the black screw in the upper left corner inside the left cover.
- ⑥ Lock the M3 self-tapping screw of the VB-232 into the mounting hole in the upper left corner inside the left cover

Install VB-485

- ① Switch off the PLC power
- ② Open the left side cover of the PLC Main Unit.
- ③ Take off the left side  shape plastic piece.
- ④ Take off the black screw in the upper left corner inside the left cover.
- ⑤ Install the base plug of VB-485 into the communication expansion slot.
- ⑥ Install the black screw in the upper left corner inside the left cover.
- ⑦ Lock the M3 self-tapping screw of the VB-485 into the mounting hole in the upper left corner inside the left cover

- There is a white-color JST4P outlet for both VB-232 and VB-485. It has the same functions as the white-color JST4P outlet on the main unit, since installing the communication expansion card will block the white-color JST4P outlet on the main unit.

6. Optional Modules

| Item | VB-232 | VB-485 |
|-----------------------------|---|---|
| Communication Interface | RS-232C | RS-422/RS-485 |
| Isolation Method | No Isolation | |
| LED Indicator | RXD · TXD | |
| Max. Communication Distance | 15 Meters | 50 Meters |
| Power Supply | DC5V 10mA (from PLC power supply) | DC5V 60mA (from PLC Power Supply) |
| Communication Protocol | Computer Link - The shared communication protocol of M, VB and VH series PLC | |
| Communication Method | Half-duplex | |
| Communication Speed | 4800/9600/19200/38400 bps | |
| Communication Parameters | Data length: 7 bits (ASCII) Parity: EVEN Stop Bit: 1 bit | |
| Number of Connected Station | 1 | 256 Max. (Install amplification device if more than 32 stations) |
| Data Transfer Range | Includes all the X, Y, M, S, T, C, D | |
| Wiring Method |  <p>2 : RXD 3 : TXD 5 : SG</p> <p>D-Sub Connector 9Pin Male Connector</p> | <p>PCB Style Terminal Block</p>  <p>Remarks: 1. RS-485 Wiring Method</p>  <p>2. SW1 is the terminal resistance switch. (Terminal resistance 120Ω)</p> |
| Parameter Configuration | For CP2 relevant parameter configuration settings please use the "System CPU Expansion Card's Communication Port Setting" function of the programming software Ladder Master. | |

6. Optional Modules

6-3 Memory Card Slot Expansion Card

- Install the Memory Card Slot Expansion Card

- ① Switch off the PLC power
- ② Open the right side cover of the PLC Main Unit.
- ③ Confirm the expansion card position, make sure the battery on the card is at the right hand side.
- ④ Plug the card into the slot in the cover with a proper strength; be careful not to damage the main unit circuit.
- ⑤ Make sure the connector of the expansion card binds with the slot connector tightly, to finish the installation.

- About the reading and configuration of the RTC (Real Time Clock) time.

Reading the RTC Time

The PLC program will automatically read the RTC time after the RTC installed to the Main Unit, and store it in D9013~D9019 for user reference.

- Un-install Memory Card Slot Expansion Card

Switch off the PLC power when un-install the expansion card. Use the small “_” shape screw driver or the IC clip to clip the auxiliary nick hole and take out the expansion card.




Configure the RTC Time

The user can configure the RTC time in 2 ways:

1. Use the “System-RTC Settings” function in Ladder Master to configure.
2. Use instruction (FNC167 TWR) to set the RTC time. This method can be used with supplementary devices like the HMI to change the RTC time.

6-4 Use the VB-MP1R

- There are 3 switches on the VB-MP1R expansion card and their functions are described below:



WE/WP Write Protect Switch WE: Write allowed/WP: Write forbidden

P ▶ M Program Upload Switch PLC program upload to MP1R enabled when it slides to the left.

M ▶ P Program Download Switch MP1R program download to PLC enabled when it slides to the left.

- Operation flow of uploading/downloading program using VB-MP1R

- Put the switch on the VB-MP1R to the right position as listed in the table below:

| Function | WE/WP | P ▶ M | M ▶ P |
|------------------|------------|-------------|-------------|
| Upload Program | WE (Left) | ON (Left) | OFF (Right) |
| Download Program | WP (Right) | OFF (Right) | ON (Left) |













- Switch off the PLC power and install the VB-MP1R in the correct direction.
- Switch on the power and start uploading/downloading programs. First the ERR LED indicator on the PLC Main Unit will flicker for 3 times then go off. During the whole process of the uploading /downloading, the ERR LED will be on all the time, and it will not take more than 1 e of the program). If anything goes wrong during the function execution process, the ERR LED will be flickering all the time.
- Switch off the power and take out the VB-MP1R expansion card.

6. Optional Modules











NOTICE

- Always put the WE/WP switch to WP when the VB-MP1R is not used for program uploading.
- Error occurs when executing uploading/downloading for the following reasons:
 - ① Password has been set for the source program
 - ② WE/WP switch is at WP when uploading.
 - ③ P ► M and M ► P switches are both at the ON (Left) side.
 - ④ Improper installation of the VB-MP1R expansion card.
 - ⑤ VB-MP1R or the PLC is malfunctioning.
- The program in the VB-MP1R will be executed first when the PLC is installed with a VB-MP1R card. And at this time, when a programming tool (e.g. Ladder Master) doing uploading/downloading, it acts for the memory in VB-MP1R as well.

6-5 Connection Cables

| Model | Picture | Connection Illustrations | Application |
|------------------------------------|---|--|--|
| MWPC-200 (Length: 200cm/6'7") |  |  DSUB 9P Female Connector  USB A-Type Connector | <ul style="list-style-type: none"> ● PC ↔ VB, VH or M Series PLC |
| MWPC25-200 (Length: 200cm/6'7") |  |  DSUB 25P Female Connector  USB A-Type Connector | <ul style="list-style-type: none"> ● PC ↔ VB, VH or M Series PLC ● Hitech HMI ↔ VB, VH or M Series PLC |
| MWMD-200 (Length: 200cm/6'7") |  |  DSUB 9P Male Connector  USB A-Type Connector | <ul style="list-style-type: none"> ● MODEM ↔ VB, VH or M Series PLC ● EASY VIEW HMI ↔ VB, VH or M Series PLC |
| VBPC09-200 (Length: 200cm/6'7") |  |  DSUB 9P Female Connector  JST 4P Female Connector | <ul style="list-style-type: none"> ● PC ↔ VB or VH Series PLC |

6. Optional Modules

| Model | Picture | Connection Illustrations | Application |
|-------------------------------------|---|---|---|
| VBPC25-200 (Length: 200cm/6'7") |  |  <p>DSUB 25P Female Connector</p>  <p>JST 4P Female Connector</p> | <ul style="list-style-type: none"> ● PC↔VB or VH Series PLC ● Hitech HMI↔VB or VH Series PLC |
| VBMD09-200 (Length: 200cm/6'7") |  |  <p>DSUB 9P Male Connector</p>  <p>JST 4P Female Connector</p> | <ul style="list-style-type: none"> ● MODEM↔VB or VH Series PLC ● EASY VIEW HMI↔VB or VH Series PLC |
| VBFDHMI-200 (Length: 200cm/6'7") |  |  <p>DSUB 25P Male Connector</p>  <p>JST 4P Female Connector</p> | <ul style="list-style-type: none"> ● FUJI HMI↔VB or VH Series PLC ● DIGITAL HMI↔VB or VH Series PLC |
| VHEC-050 (Length: 50cm/19.7") |  | — | <ul style="list-style-type: none"> ● Extended cable for a VH Series PLC Extension Unit/Module. (Keep away from interference during wiring job for the data transferred in this extended cable is unprotected and easy to get interferred.) |

7. Operation Rehearsal, Maintenance and Error Checking

Operation and Maintenance Safety Notes **DANGER**

- DO NOT contact the terminal when the power supply switched on, to avoid electric shock or product mis-reaction.
- Switch off the power supply before clean or tighten the terminal, to avoid electric shock.
- Carry program-change-in-operation (force output, RUN, STOP, etc) ONLY after carefully read and understand this manual and safety is ensured, for misoperation may cause equipment damage or accident.

Operation and Maintenance Safety Notes **CAUTION**

- Switch off the power supply before assemble or overhaul the selected optional units, to avoid damage to the expansion or main units.
- Switch off the power supply before assemble or overhaul the connection cable, to avoid damage or misoperation.
- DO NOT assemble or overhaul the product cage, or alter it by yourself, for it may cause product damage, mis-reaction or fire.
- Contact the nearest distributor or Vigor Electric Corp directly for any product repairing matters.

7. Operation Rehearsal, Maintenance and Error Checking

7-1 Operation Rehearsal

- Perform the pre-rehearsal examination with the power supply switched OFF.
Incorrect power terminal connection, short circuit of DC input and power supply wirings or short circuit of output wirings will cause severe damage to the PLC. So DO check the power and input/output wirings before switch on the power, to make sure everything correct.
- Perform the program examination when the power supply ON and PLC STOP.
Upload the program within the PLC using programming tool and make sure it is correct. The user can also use the “compile program” function of the programming tool to make sure the circuit and grammar are correct.
- RUN/STOP Switch of the PLC
There is a RUN/STOP switch on the PLC. When the PLC power goes from OFFON, the PLC will enter RUN/STOP mode according to the setting of the RUN/STOP switch. And then the RUN/STOP status can be controlled by the RUN/STOP switch and the programming tool.
- Perform the operation rehearsal test when the power is ON and PLC is RUN.
The CPU will execute self-examine function once the PLC power goes from OFFON.
If there is no exception, the PLC enters operation mode. (RUN LED is ON.)
If there is program error (grammar or circuit error), the ERR LED will flicker, and PLC stop running.
If there WDT triggered, the ERR LED will flicker, and PLC stop running.
Force ON/OFF action can be performed on many components during the program operation.

7. Operation Rehearsal, Maintenance and Error Checking

7-2 Determine Exceptional Behavior through the LED Indicator

When problem occurs during PLC operation, check the power supply voltage, the terminal screw and connection cable (may be loose), and the I/O component (may be faulty). Then check the PLC LED indicator. These indicators help to analyze the error is caused by PLC or external components.

- PWR Power Indicator LED (Green)

When power supplied, the PWR indicator LED on main unit panel will be ON. If it is not, check the power circuit wiring and make sure correct voltage is used. Else, may send PLC back for repairing.

- RUN Operation Indicator LED (Green)

When the PLC operates well, the RUN indicator LED on the Main Unit panel will be ON. If the PLC is at STOP status or any error occurs, the RUN LED will be OFF.

- ERR Error Indicator LED (Red)

When error occurs to the PLC, the error indicator LED ERR on main unit panel will be ON or flickering.

<ERR LED Flicker>

ERR LED flickers when program changed by improper use, broken circuit, exceptional interruption, and invasion by conductive materials, PLC will STOP and all outputs turn OFF. When this happens, please double-check the program, and whether there is powerful interruption source or conductive materials invasion.

<ERR LED ON>


ERR LED turns ON when the CPU out of control and WDT occurs caused by PLC circuit broken or exceptional external interruption, PLC will STOP and all outputs turn OFF. When this happens, please switch off the PLC power supply and switch it on again. If this recovers the PLC normal operation, please double-check whether there is powerful interruption source and whether the PLC grounding is fine. If the ERR LED is still ON, the PLC may be faulty, consider sending it back for overhauling.

7. Operation Rehearsal, Maintenance and Error Checking


- INPUT X Input Status Indicator LED (Upper half of the Display)
 - (1) If the input status indicator LED is not as expectation, please make sure the external input switch status is fine.
 - (2) Loose switch contact may be caused by over-strong input switch current or invasion of oily dirt.
 - (3) When parallel LED circuit included in the input switch, the input signal of the PLC may be ON even when the switch is OFF.
 - (4) The sensitivity of photoelectric switches might be affected by dirt-stuck, and cause it failed to switch to ON mode.
 - (5) The PLC may not be able to judge the input status accurately if the input switch ON/OFF time is shorter than the PLC scanning time.
 - (6) The PLC input circuit may not be able to work well when the DC24V power supply used by it is excessively used or has short circuit.
 - (7) The input circuit might be damaged if the voltage put on it exceeds the appointed limit.
- OUTPUT Y Output Status Indicator LED (Lower half of the Display)
 - (1) If the load doesn't work as the output indicator LED status, please check whether the external load function is fine.
 - (2) Melting or short circuit of the PLC output point may be caused by overload, short circuit load or surge current of the capacitor load.
 - (3) Relay point loose contact may be caused by the excessively frequent action of the PLC output point.
- Refer to the Error Examination Flow Chart on the next page for advance examinations.

7. Operation Rehearsal, Maintenance and Error Checking


First Examine Stage



Second Examine Stage



Third Examine Stage



7. Operation Rehearsal, Maintenance and Error Checking

7-3 Maintenance

Recycling Safety Notes CAUTION

- Dispose the product as industrial waste when it is to be discarded as worthless.
- The product does not include short-life consumptive parts, so there is usually no need to change parts.
- If the output relay works frequently, or is used to drive big capacity load, please perform constant check on it.
- Perform the following general checks constantly:
 - (1) Does other heat source or direct sunlight cause the internal temperature of PLC raise abnormally?
 - (2) Is there dust or conductive dust invasion into the PLC?
 - (3) Do any of the connection cables or connection terminals, etc, become loose?